



# **Photo Editing Software For SL620**

---

## **User Manual Version 3.5\***

---

**For DNP printers  
and HID Fargo DTC 1250e ONLY**

*\*This Manual is only about the 3.5 Update, for the full version please refer to DNP website/Downloads/Manuals.*

March 2021  
Version 1.0

---

# SUMMARY

- SUMMARY .....2**
- 1. LICENSE AGREEMENTS, TERMS & CONDITIONS .....3**
- 2. NEW FEATURES .....4**
- 3. PAYMENT METHODS .....5**
- 4. IDENTITY .....8**
  - Manual modifications.....8
- 6. STATISTICS.....9**
- 7. TROUBLESHOOTING .....10**
  - DNP PIE Support team contact details ..... 10
  - Local immediate print product is no longer available..... 10
  - User manual ..... 10

---

## 1. LICENSE AGREEMENTS, TERMS & CONDITIONS

Please refer the original user manual of Snap Lab Plus v1.8 for the following items:

- Snaplab+ Software Licensing Agreement
- Ownership Retained By Licensor
- Disclaimer of Warranties
- Limitation of Liability
- Governing Law
- Terms & Conditions
- Acknowledgments
- ICC Profiles

---

## 2. NEW FEATURES

The new Snaplab+ version 3.5 includes these new features/improvements:

- Payment methods: selection of the payment on user side (by credit card or at the cash desk)
- ID: biometric report improved with manual modifications icons
- Statistics: automatic backup with timing selection

### 3. PAYMENT METHODS

From this new version, it is now possible to offer 2 payment modes to your customers: by credit card or at the cash desk.


Payment by credit card is only possible through SumUp. The order is printed once the transaction has been validated.


For payment at the counter, the terminal prints the receipt for the customer. The customer goes to the counter to pay for his order with his receipt. The operator gives him a new ticket with a barcode. The customer then returns to the order terminal, scans the barcode and gets his or her photos.

- 1) From the main menu, press on *Settings* button





- 2) In the General column, press the *Process Confirmation* button. Choose the desired order confirmation mode. You can add card payment (in addition to counter payment) for the following 4 modes: confirmation with password, confirmation by numeric keypad, manual triggering by operator, barcode print triggering.






- 3) Once the order confirmation mode is selected, enable payment by credit card with the *Allow payment by credit card* button by selecting Yes. You can also define some SumUp settings.






- 4) User/customer workflow: after validation of the order, a new screen appears offering 2 payment options.




## 4. IDENTITY

### Manual modifications




Note: If you make modifications on rotation or cropping (for example), SL+ software will analyse your changes according to current biometric criteria and will display a custom biometric report. By default, software incorporates a margin of tolerance for changes.



Important: For any manual modification, the software displays a "warning sign" icon in the biometric report (in the example, this is the manual cropping and manual rotation). This icon means that the manual modification made is within the modification tolerance. If your changes are outside the change tolerance zone, you will see a red cross on the biometric report. This means that your photo does not meet the biometric standards.

## 6. STATISTICS

You can now define the frequency of your automatic statistics export. To do this, click on the *configuration* button (in the statistics menu), select the source folder and the desired frequency of saving.



---

## 7. TROUBLESHOOTING

---

### ***DNP PIE Support team contact details***

For any technical issue(s) and/or question(s), please contact DNP PIE support team at:

[support@dnpphoto.eu](mailto:support@dnpphoto.eu)

---

### ***Local immediate print product is no longer available***

If you are using DNP printers, the software automatically hides the products which cannot be processed. Make sure the printer is powered on, with available media, connected to the Terminal and ready to print.

---

### ***User manual***

This Manual is only about the 3.5 Update, for the full version please refer to DNP website/Downloads/Manuals:  
<http://dnpphoto.eu/en/support-and-downloads/manuals-brochures/manuals/dp-sl620-2/85-sl620-user-manuals>